ASM

100

User Manual

aram HUVIS

Contents

Components

Skin lens
(ASM 100)

Main unit with hair lens
(ASM 100)

Cradle

Sebum paper
(100ea)

Charger

USB cable

Cleaning cloth

Manual

Air blower

Device Functions

ASM lens

LED Indicator

Volume up & down button

On/off button

Lens module change button

X1 lens

USB slot (DC 5V 3A)

Power On/Off

To turn on & off the power

1 Press the power button and hold.
2 Then "LED Indicator" will be twinkle and turn to white.

Charger can be used for American type & European type. The default is European type.

1 Push the plug up.

2 Then European type is disassembled and you can see the American type inside of the charger.

3 Choose the one you want to use and connect USB cable in adaptor.

Battery / Status LED Indication

Status LED — Deco LED

CAMERA POSITION	STATUS	DECO LED	STATUS LED	
In use	While turning it on	Light on	Blue light	🔵
In use	When running the app	Light on	Off	⚪
In use	Low battery	Displayed only on the indicator at the top of the LCD screen		
Plugged to the base	Charging	Off	Red light (When the LCD screen is off)	🔴
Plugged to the base	Fully charged (180 minutes)	Off	Blue light (When the LCD screen is off)	🔵

Taking off the lens

**1** Press switching button located below the lens for switching the lens.

2 Turn the lens about 45 degrees counter-clockwise while pressing the switching button to take off the lens.

Inserting lens

1 Until the correct lens is inserted, lens indicating label will blink.

2 To insert the lens, match the red dot on lens and gray dot on device, turn it clockwise until clicks.

Date & Time

❶ Press ⮌ button to return to homepage.

❷ Touch ⚙ button.


❸ Go to "Date & time"

❹ Go to "Set date".


❺ Select the date and touch "OK" button.

❻ Check if the setting is correctly applied.

Date & Time


❼ Touch "Select time zone"

❽ Select proper time zone.

❾ Check if the setting is correctly applied.

❿ Touch "Set time".


⓫ Change into the current time and touch "OK" button.

⓬ Check if the setting is correctly applied.

Wi-Fi

❶ Touch ⚙ button.

❷ Touch "Wi-Fi".

❸ Turn on toggle switch.

❹ Select Wi-Fi

❺ Among the lists, select the Wi-Fi connection you could use.

❻ Wait until the device is connected to Wi-Fi.

# Application Settings



❶ Touch ⚙button.

❷ Go to "General Settings".

❸ Available to change Language, Version and Email setting.

❹ Select skin type and analysis criteria at skin analysis setting.

❺ Register corresponding products at recommended product setting.

❻ Proceed update at information.

Customer

❶ Touch "Customer".


❷ Touch ➕ to register new customer.

❸ Input the information.

❹ After putting all information, touch ✓.

❺ Select created user profile.

❻ Touch 🔬 button to start analyzing.

Moisture

❶ Touch the 📷 button. Please wait until vibration and sound.
* Never put the sensor on the skin before the message "Touch to skin please".

❷ After checking the message "Touch to skin please", push the sensor completely to marked area of the face.
* All surface of the sensor should be pushed completely.

❸ Analyzing hydration and elasticity…

❹ Check the result. To move on next page, slide the screen from right to left.

Sebum

❶ Press pink part of sebum paper on U-Zone for about 2~3 seconds.


❷ Capture image of pink part of sebum paper.

❸ Press pink part of sebum paper on T-Zone for about 2~3 seconds.

❹ Capture image of pink part of sebum paper.

❺ Press 🔬 button to analyze.

❻ Sebum result will appear.

Pore

❶ Check capturing part and press 📷 button to get into capture mode.

❷ Focus on image which you wish to capture.

❸ Press 🔍 button to analyze.

❹ Result will appear. Press button to compare against sample.

❺ Touch ⚖️ button to compare taken image with 3 sample images. - Good/Normal/Bad

❻ Touch 📦 button to convert taken pore image in 3D.

Melanin

❶ Check capturing part and press 📷 button to get into capture mode.

❷ Focus on image which you wish to capture.

❸ Press 🔬 button to analyze.

❹ Result will appear. Press button to compare against sample.

❺ Touch ⚖ button to compare taken image with 3 sample images.
- Good/Normal/Bad

Acne

❶ Check capturing part and press 📷 button to get into capture mode.


❷ Focus on image which you wish to capture.

❸ Press 🔬 button to analyze.

❹ Result will appear. Press button to compare against sample.

❺ Touch ⚖ button to compare taken image with 3 sample images.
- Good/Normal/Bad

Wrinkle

❶ Check capturing part and press 📷 button to get into capture mode.

❷ Focus on image which you wish to capture.

*For wrinkle photo, take picture of outer eye area in widthways to check crow's feet.

❸ Press 🔬 button to analyze.

❹ Result will appear. Press button to compare against sample.

❺ Touch ⚖ button to compare taken image with 3 sample images.
- Good/Normal/Bad

❻ Touch 📦 button to convert taken pore image in 3D.

Sensitivity

❶ Check capturing part and press 📷 button to get into capture mode.

❷ Focus on image which you wish to capture.

❸ Press 🔬 button to analyze.

❹ Result will appear. Press button to compare against sample.

❺ Touch ⚖ button to compare taken image with 3 sample images.
- Good/Normal/Bad

Summary

❶ Touch ▨ button or "Show All Result" to see overall result.

❷ You can check result. Care-needed part will be in red.

Send Result - Email

❶ Before sending Email, the device shall be connected to Wi-Fi.

❷ Touch ••• .

❸ Go to "Send Email".

❹ Select "Gmail"

❺ Select email account.

❻ Share the result by sending email.

Mirroring

❶ Touch ⚙ button.

❷ Go to "General Settings".

❸ Turn on mirroring option.

❹ Transfer to app download page using QR code.

Mirroring

❺ Install "Aram Viewer" on device which you will be mirroring.

❻ Move to "Wi-Fi" setting.

❼ Select device's SSID.

❽ Mirroring will be started.

View Mode

❶ Touch "View".

❷ You can analyze with multiple modes.

❸ You can compare 2 pictures.

❹ You can mark on screen using pen.

Warranty

① The product undergoes strict quality management and inspection process before production and introduction to market.

② In case of functional or operational defect occurs under normal condition of use within 10 days after purchase, we will repair it for free or replace in new product.

③ When this product goes out under the normal use, we will repair it free of charge under warranty.

④ Please keep the warranty card when you ask for repair service.

⑤ Customer needs to pay repair charge after warranty runs out.

⑥ For this product, warranty period is 14 months from the Invoice date.

⑦ Cost
Within warranty : Sending delivery(Buyer), repair cost and returning delivery(Aram)

- If the product is broken by user's fault, repair cost could be charged.
- After warranty : Sending delivery and repair cost(Buyer), returning delivery(Aram)

⑧ How to send :

- As sending a present from person to person by EMS or FEDEX.
(Do not write the company name)

- Total value should be under US $ 99.(Write non-commercial value)

Warranty

Service request form			
Date of purchase	/ /	Company	
Contact person			
Address : Tel :			
Product name, serial No : Problems :			

SHIPPING ADDRESS :

#801 Byucksan Technopia, 560, Dunchon-daero, Jungwon-gu, Seongnam-si, Gyeonggi-do, 13230 Republic of Korea

Tel: 070-4687-1712 / Fax: 031-732-6330 / Email: support@aramhuvis.com
http://www.aramhuvis.com

Memo

aram HUVIS

HEAD OFFICE
#401~402 Bundang Seoul National University Hospital Health Care Innovation Park, 172, Dolma-ro, Bundang-gu, Seongnam-si, Gyeonggi-do, 13605 Republic of Korea

PRODUCTION DIVISION & FACTORY
#909 Byucksan Technopia, 560, Dunchon-daero, Jungwon-gu, Seongnam-si, Gyeonggi-do, 13230 Republic of Korea

Tel: 070-4687-1712 / Fax: 031-732-6330 / Email: info@aramhuvis.com
http://www.aramhuvis.com